

BASIC WIRING GUIDE.

Select the appropriate wiring scheme to match
the input requirements of the Hunza fittings to
be installed

