

THE “MOUSE LITE™” SQUARE LUMINAIRE INSTALLATION INSTRUCTIONS



NOTE: THESE INSTRUCTIONS MUST NOT CONTRAVENE YOUR LOCAL ELECTRICAL AUTHORITY REGULATIONS, WITH WHICH ALL INSTALLATIONS HERE IN MUST COMPLY. PLEASE KEEP INSTRUCTIONS FOR FUTURE REFERENCE.

12VAC

The Mouse Lite™ is designed as a surface mount luminaire. Make a water proof connection using heavy walled adhesive heat shrink, between the luminaire cables and the low voltage supply cables. Screw the luminaire onto the wall through the holes in the front.

110VAC Wiring

Make a waterproof connection to the phase (active) wire and the Neutral wire of the fitting. Connect earth wire to the green wire of the fixture. Screw the luminaire onto the wall through the holes in the front.

DO NOT connect in close proximity to inductive loads, eg. air conditioning systems.

Warning - Take care to place the luminaire in a suitably safe position, due to the operating temperature of the luminaire.

Recommendation:

Use Hunza CJK#150 Cable Joint Kit.

It is recommended that high quality halogen capsules are used when replacing existing capsules.

HALOGEN CAPSULE CHANGING

CAUTION: Make sure that the power to the luminaire is switched off before attempting to change the lamp. Beware of hot luminaire and lamp. Make absolutely sure when changing lamps that the correct wattage lamp is installed. If an incorrect wattage is used it may cause HUNZA™ IG series transformers to overload causing the transformers to heat up and turn the luminaires off and on.

WARNING: Do not touch halogen capsule with bare fingers, leave plastic bag over the capsule & push into the lamp holder. Then remove plastic bag before switching fitting on.

Maximum Wattage 25 Halogen Capsule.

Stainless Steel Maintenance: To maintain the finish of 316 stainless steel it is recommended to wash the luminaire with fresh water from time to time to stop salt and corrosive elements building up. If tea staining appears, a commercially available stainless steel cleaner is recommended to remove this. Electro polishing is recommended in this situation but the fitting will still require regular maintenance. Even an electro polished stainless steel fixture under an eave or roof will suffer from the build up of salt deposits as it will not be washed away by rain.

THE “MOUSE LITE™” SQUARE LUMINAIRE INSTALLATION INSTRUCTIONS



NOTE: THESE INSTRUCTIONS MUST NOT CONTRAVENE YOUR LOCAL ELECTRICAL AUTHORITY REGULATIONS, WITH WHICH ALL INSTALLATIONS HERE IN MUST COMPLY. PLEASE KEEP INSTRUCTIONS FOR FUTURE REFERENCE.

12VAC

The Mouse Lite™ is designed as a surface mount luminaire. Make a water proof connection using heavy walled adhesive heat shrink, between the luminaire cables and the low voltage supply cables. Screw the luminaire onto the wall through the holes in the front.

110VAC Wiring

Make a waterproof connection to the phase (active) wire and the Neutral wire of the fitting. Connect earth wire to the green wire of the fixture. Screw the luminaire onto the wall through the holes in the front.

DO NOT connect in close proximity to inductive loads, eg. air conditioning systems.

Warning - Take care to place the luminaire in a suitably safe position, due to the operating temperature of the luminaire.

Recommendation:

Use Hunza CJK#150 Cable Joint Kit.

It is recommended that high quality halogen capsules are used when replacing existing capsules.

HALOGEN CAPSULE CHANGING

CAUTION: Make sure that the power to the luminaire is switched off before attempting to change the lamp. Beware of hot luminaire and lamp. Make absolutely sure when changing lamps that the correct wattage lamp is installed. If an incorrect wattage is used it may cause HUNZA™ IG series transformers to overload causing the transformers to heat up and turn the luminaires off and on.

WARNING: Do not touch halogen capsule with bare fingers, leave plastic bag over the capsule & push into the lamp holder. Then remove plastic bag before switching fitting on.

Maximum Wattage 25 Halogen Capsule.

Stainless Steel Maintenance: To maintain the finish of 316 stainless steel it is recommended to wash the luminaire with fresh water from time to time to stop salt and corrosive elements building up. If tea staining appears, a commercially available stainless steel cleaner is recommended to remove this. Electro polishing is recommended in this situation but the fitting will still require regular maintenance. Even an electro polished stainless steel fixture under an eave or roof will suffer from the build up of salt deposits as it will not be washed away by rain.